



S4013
**Aluminium Sharpener
Double Cone**
Sacapuntas de Aluminio
Cono Doble

Carton Caja 720 pcs




S4014
**Aluminium Sharpener
Single Cone**
Sacapuntas de Aluminio
Cono Solo

Carton Caja 1440 pcs



S4015
**Aluminium Sharpener
Single Cone-Rectangle**
Sacapuntas de Aluminio
Cono Solo - Rectangular

Carton Caja 1440 pcs



S4011
**Pencil Sharpener
Double Cone**
Sacapuntas de Plastico
Cono Doble

Carton Caja 1440 pcs



S4012
**Pencil Sharpener
Single Cone**
Sacapuntas de Plastico
Cono Solo

Carton Caja 2880 pcs



S4009
Pencil Sharpener With Container
Sacapuntas con Deposito

Carton Caja 720 pcs



S4006
Sharpener With Container
Sacapuntas con Deposito

Carton Caja 720 pcs